Fiat Ducato 2.3D timing belt guide

The 2.3-litre diesel engine is used in the popular Fiat Ducato since 2002 and equivalent Iveco Daily from 1999. Dayco recommend that all the systems' components - timing drive and auxiliary drive - be replaced at the same time. This step-by-step technical guide will help technicians through the process, to avoid complications and ensure a first-rate job.

A swith all primary drive system jobs, the work should be undertaken when the engine is cold, so ideally the vehicle will not have been run for at least four hours.

(i) Tech Tips

From under the vehicle, remove the case to expose the air conditioning compressor and outer auxiliary belt, followed by the cowling under the right-hand wing, to gain access to and remove the belt.

By using a spanner on the automatic tensioner to reduce the tension on the inner auxiliary belt (figure 1), remove the belt, then the tensioner and the idler,



followed by the crankshaft pulley, which is secured by four bolts.

Remove the valve cover on top of the engine and, in order to move them out of the way, detach the coolant and steering fluid reservoirs from the bracket and then remove the bracket to access the top engine mount. Suitably support the engine



from below and remove the top mount and then the plastic timing belt cover, to expose the timing drive system.

To aid the removal of the existing timing belt, remove the front right headlamp unit, and then insert the crankshaft timing tool into the hole adjacent to the crankshaft pulley (figure 2) and the two camshaft timing tools through the holes in the top of the valve cover. Secure the camshaft pulley with the appropriate tool and slacken the pulley bolt, which while remaining centred, should allow the pulley to rotate on the camshaft end.

Slacken the tensioner bolt and remove the belt, followed by the tensioner and the toothed idler. Replace the old toothed idler with the new one in the Dayco KTB339 kit, and tighten the bolt to 35Nm of torque, then install, but do not tighten, the new tensioner.



Secure the camshaft pulley with a 5mm Ø pin and fit the new HT belt with the timing mark on its back, aligned to the timing mark on the camshaft pulley and following the direction of rotation arrows, leaving the slack side of the belt facing the tensioner. Then remove the camshaft pin and using an allen key, rotate the tensioner so that the small red dot is in the position shown (figure 3) and temporarily fasten the tensioner.

Again using the appropriate tool, tighten the camshaft pulley to 90Nm of torque and then remove the crankshaft and camshaft timing tools, rotate the engine eight complete rotations by hand and reinsert the timing tools.

Rotate the tensioner so that the small red dot is positioned in the secondary position (figure 4) and tighten the fastening bolt to 35Nm of torque. Remove the timing tools, rotate the engine another two complete rotations by hand and check that the timing tools can be reinserted, which will ensure that the valve timing is correct. Naturally repeat the process should the tools fail to locate correctly.



Once the correct timing has been achieved, remove the timing tools and reassemble the components. Replace the auxiliary belt crankshaft pulley (Dayco DPV1031), idler (Dayco AVP1074) and tensioner (Dayco APV1075), plus the two auxiliary belts (Dayco 7PK1076 and 4PK903EE) and reassemble the remaining components.

For more information regarding the OEM quality power transmission products in the Dayco range, please email info.uk@dayco.com or visit www.dayco.com.

