## Bulletin

## Apec

## Modified hand brake lever

**FULL SPEC. FULL STOP.** ™

Date: 25th June 2009

For part numbers/make & models: SHU 623, SHU 624, SHU 661

The hand brake lever on the above part numbers of shoe have been modified to overcome certain fitting issues.

To ensure our customers are fully aware of how the brake cable should be fitted to the new lever design, we show here via the photographs how it should be assembled.

1. Cable is inserted into lever end as shown here.



2. The outer spring sleeve is placed as shown and then the lever is crimped as shown to complete the assembly.

