Technical Bulletin

Bolt Torque Settings

Ford 2.2 & 2.4 Duratorq



Best Practice:

After installation, stamp the damper pulley bolt head with a centre punch to indicate usage. The bolts should be tightened in 2 stages **Stage 1:** 30 Nm **Stage 2:** +90 degrees



Best Availability. Best Value. Best Quality. Best Service.





May 2018

+44 (0) 1525 351800



TB0013

