

Cables



# FKC1479

## Citroen Berlingo / Peugeot Partner Van - 1996 to 2005 Auto-Adjust Clutch Cable

CATB 0002

1. Starting with the auto adjust mechanism fitted in the spring retention clip (middle of chassis sub-frame) - route cable upwards, towards firewall - Slide the cable end fitting up through the Firewall Grommet "home".



2. PLEASE NOTE Correct routing of the cable when routing to the Bulkhead from retention clip is in the middle of the PAS (Power Assisted Steering) Pipe - should not be on the bulkhead side of this pipe as this will result in incorrect routing of the cable and cause adjustment problems.
3. Route gear box cable end via two cable locating hooks as shown below



4. Fit the Grey plastic moulded "cup" into clutch actuation lever.
5. Fit rubber grommet into gear box bracket (easier fitting use a water or silicon based lubricant)



Continued...