

Mountings
and Bushes



Ford

Mondeo III 2000-

MBTB 0002

FSK6410 / FSK6411

Ford Mondeo III rear subframe bushes

SPECIAL INSTRUCTIONS & FITTING TIPS

Thoroughly clean the mounting holes in the subframe prior to installation of the new bushes.

Apply **Loctite270** © to the outer circumference of the bush and ensure that it is correctly aligned before pressing in.

IMPORTANT NOTE

The vehicle may be moved but must not be driven for 24hrs to allow the **Loctite 270** © to fully cure.

First Line recommend that the subframe bushes are replaced as a full set.



FSK6410
Front 'V Shaped' head



FSK6411
Rear straight head

FIRST LINE 
THE ALL MAKES SPECIALIST

May 2012

www.firstline.co.uk

TECHNICAL INFORMATION