



Ford Transit, build from 08.94

Some vehicle in this build range experience condensation water ingress via the ventilation in to the foot well when the air conditioning is running.

To rectify the problem:

Ford offers a collecting tray with a drainpipe which is mounted under the heater.

1. Remove the gear stick
2. Release the carpet round the gear stick
3. Fit the collecting tube in the right mounting position
4. Position the drain pipe hole on the floor
5. Make a hole for the rubber cuff
6. Install the rubber cuff and the carpet
7. Make the same hole for the drain pipe in the carpet
8. Fit the drain pipe and the gear stick

Regards

Your Service Partner Technical Team

Bulletin