

# Technical Bulletin

Technical Helpline: +44(0)1622 833004 Fax: +44(0)1622 834004

## Toyota Rav 4 (Model ACA20/21 - 1AZ-FE) Oxygen Sensor Identification from Fault Codes

Date Issued: 10/03/08

### Year Range = 5/00> 7/03

On the Toyota Rav4 2.0VVTi built between May 2000 and July 2003 there are four Oxygen Sensors fitted. These appear in the Blue Print catalogue as LH/RH Upper/Lower.

When one of these oxygen sensors fails the obligatory engine management warning light will come on. Using an appropriate diagnostic tool or by checking the 'blink' code, it will identify the faulty sensor as either Bank 1 or 2, and Sensor 1 or 2.

### To help select the correct sensor on the vehicle you will need to know the following:

Bank 1 = LH                      Sensor 1 = Upper

Bank 2 = RH                      Sensor 2 = Lower



**So a fault code that comes up with Bank 1/Sensor 2 will be indicating the LH lower oxygen sensor is at fault.**

**When one of these oxygen sensors fails, the obligatory engine management warning light (MIL) will come on.**

**Disclaimer :** Any technical tips are produced in good faith. Blue Print, always recommend that vehicle maintenance and diagnostics are only carried out by suitably experienced people using appropriate tools in a safe manner within a workshop environment. Blue Print, and their customers cannot be held responsible for the correctness of, or misinterpretation of the above technical tips. Images shown are for illustrative purposes only and may not be representative of the products or vehicles described.