



## **BMW 5serie (E39) all models with climate control**

### **Intermittent heating of the foot well.**

If, on this vehicle is mentioned that the foot well is intermittently heated, a possible cause could be the following: If the temperature setting is cold and the airflow through the centre vents is chosen, it is possible that the down draught of cold air is sucked in by the small blower of the interior temperature sensor (picture). Due to this the climate control recognises too low temperature and increases the heat, especially to the foot well air outlet.

To prevent this process, the temperature setting should be higher, an other air outlet should be chosen or the vent position changed so the air is not directly downwards.



**Bulletin**