



## ***BMW all new models (E60, E65,...) with tyre pressure check***

### **Light for tyre pressure check illuminates**

If with the above-mentioned vehicles the check light for the tyre pressure monitoring system illuminates, this can be caused by the spare wheel being in the wrong position. The message "Signal sensor spare wheel faulty" will be stored in the fault memory.

In particular within the context of a regular service or after tyre pressure has been checked, care must be taken that the tyre valve is back in the 9 o'clock position (see photo) when the spare wheel is put back. Only in this position will the receiver recognise the signals transmitted.

