



Important information for the repair of an air-conditioning system with a damaged compressor.

When carrying out a repair to an air conditioning system with a damaged compressor it is absolutely necessary to clean (flush) the complete system. This is required to ensure that all pollutions, for example metal shavings, are removed from the system components. Except the dryer / accumulator this must be replaced every time. If the system is not cleaned it is possible that the newly fitted compressor could be damaged again. These damages are viewed by the manufacturer as guarantee refusals due to incorrect repair. To save the customer, garage and wholesaler / manufacturer a lot of cost, work and trouble it is necessary to clean the system. The required equipment can be found in the Hella spare parts catalogue.

We point out once more, that the oil capacity of new compressors must be checked and if necessary corrected. Please be aware that the compressor, after fitting, must be turned a few times by hand to ensure full lubrication before running with the engine. Our TI, Repair / Service, "Repair Tips" contains more detailed information.

Bulletin