

© Hella KGaA Hueck & Co., Lippstadt

4 September 2007



Indicator switch does not reset automatically.

If there are complaints with these vehicles that the indicator switch does not reset automatically after indicating, one possible cause is a broken-off reset cam on the airbag clock spring. In order to eliminate the fault, the clock spring must be replaced and a spacer ring additionally fitted.

Bulletin





1-1