



Ford Scorpio from model year 1995 with petrol engine

Coolant warning light is on continually.

If there are complaints with these vehicles that the coolant warning light is on all the time, one possible cause is a faulty float in the surge tank. Proceed as follows for fault diagnosis:

- Make sure that the coolant level in the surge tank is OK.
- Remove the plug from the coolant level switch in the surge tank.
- Switch the ignition on and bridge the two contacts in the coolant level switch plug.
- If the warning light goes off, the float in the surge tank is faulty.

To eliminate the fault the surge tank has to be replaced. The control switch has to be installed in the new surge tank.