



Land Rover Freelander With Td4 engine

Engine starts poorly or starter does not turn.

If there are complaints with these vehicles that the engine starts poorly, or that the starter no longer turns, one possible cause is an oxidized earth connection. The earth connection between the battery and the transmission is affected. The earth cable is screwed onto the front of the transmission, below the air-filter box. The oxidation cannot be detected by a visual check. Only after removing the fastening screw does the heavy oxidation on the head of the screw and on the earth cable become visible.

In order to eliminate the fault, the earth cable and the fastening screw must be cleaned.

Bulletin

