N10/2.

© Hella KGaA Hueck & Co., Lippstadt

4 April 2007

## *Mercedes Benz S-Class (W 140) SL-Class (W 129*

## Constant illumination of the right or left indicator or headlight.

If there are complaints with these vehicles that the right or left indicator or headlight shines constantly even when the ignition is switched off, one possible cause may be a defective combination relay. In order to eliminate the fault, a new combination relay must be fitted. In the case of both vehicle types, the relay is fitted in the fuse/relay box in the engine bay, on the right, below the windscreen. In Type 129, the combination relay is plugged into slot H . In Type 140, the combination relay is plugged into slot N10,

Bulletin





1-1