



## **Opel Corsa / Agila 2001-2002 With Z10XE, Z12XE engine**

### **Engine does not start or runs roughly.**

If there are complaints with these vehicles that the engine does not start up or runs roughly, one possible cause could be the immobiliser control unit not recognising the deactivation signals. These signals are modified through interference to such an extent that they are no longer recognised by the immobiliser control unit. The engine control unit stores the fault code P1612 (no or incorrect signal for immobiliser).

If the fault occurs, switch off the ignition (key position 0), wait for 5 seconds, and then restart the engine. The engine will start normally.

To eliminate the problem, all ground connections for the engine and bodywork as well as plug connections for the engine control unit and immobiliser control unit must be checked to make sure that they are seated correctly and making proper contact.

Delete the fault code in the control unit.