



Opel Corsa B, Astra F, Vectra B, Calibra, Omega B with daytime running light (daytime running light switching, Scandinavia)

Daytime running light remains on after switching the engine off.

If there are complaints with these vehicles that the daytime running light remains on after switching the engine off, and that, as a result, the battery is discharged, one possible cause is a defective relay. Due to the high current flow, the contacts burn and cannot be separated after switching off the engine.

In order to eliminate the fault, a new, more powerful relay must be fitted for the daytime running light.